



## Quick Installation Guide

MultiPlus-II 48V 3000VA 230V<sub>ac</sub>


Included



For fuse values:  
refer to the user manual

Fuse (not included)


Not included




Battery

Battery Cable +


Battery Cable -



Remote control




UTP-Cable




Current Transformer




AC-OUT



AC-IN




2




Terminals explanation  
Read the manual


- 1 - Remote On/Off
- 2 - VE Bus
- 3 - VE Bus
- 4 - AUX I/O
- 5 - Current Sense
- 6 - Aux Relay




3




5




7




9




4



6



8



10