






0

Tools you may need




metal press



angle grinder
max. 400 r/min!



metal
shears




nailer


1

Roof preparation


1.1




1.2



1.3.1




1.3.2




1

Roof preparation


1.4.1




1.4.2




1.4.3




1.4.4




1.5.1



1.5.2






2

Etile technical information


2.2



3

Etile installation precess











3.1



3

Etile installation precess


3.2




3

Etile installation precess

3.3.1




3.3.2



4

Voilà!



In case you need help in any step of the installation process, please contact our staff.



www.electrotile.com
e-mail: support@electrotile.com